

## **Submittal Sheet**

| Westpac Ultra Fill  |  |
|---|--|
| • Output       • Output         • Output       • Output | Ultra Fill is a light weight gypsum<br>based compound used for pre-<br>filling, leveling, patching and<br>filling interior walls and ceilings.<br>It is GreenGuard Gold certified.<br>MADE IN THE USA                        |
| What is it?   | Ultra Fill is an easy mixing compound reinforced with<br>fiberglass fibers that is designed to fill voids without cracking<br>or shrinking.  |
| Why do you need it?   | It adheres well to concrete, plaster, drywall, brick or any other<br>properly prepared clean and sound substrate. It fills voids and<br>patches 1" thick or more with one coat. Ultra Fill is Class A<br>rated per ASTM E84. |
| Set Times:  | This product has an approximate working time of 80 minutes,<br>set time of 90-120 minute and a scrapability and/or double<br>coat time of approximately 15 minutes after the initial set time.                               |
| Limitations:  | Ultra Fill is for interior use only. The substrate must be stable, clean, dry and free from any form release agents.   |
|   |  |

## Ultra Fill Data Sheet

| 1. Recommended Use –             | For interior walls and ceilings, use for pre-filling, leveling, patching and filling voids up to 1" thick. Ultra Fill may be top-coated with appropriate finishing compounds and paints.   |
|----------------------------------|--|
| 2. Packaging                     | 33 lb. 15 kg Bag   |
| 3. Yield                         | Approximately 6 gallons (23 liters)  |
| 4. Mixing                        | Mix in a clean container with clean water, approximately 3.3 gallons<br>per 33 lb. bag. Slowly add powder to water and continue mixing<br>until free of lumps. Mix no more material than can be used prior to<br>material hardening.           |
| 5. Job and Surface<br>Conditions | Maintain a minimum air temperature of 50° F (10° C) during application,<br>and until completely "dry" and stable. This product is for interior use<br>only. The substrate must be stable, clean, dry and free from any form<br>release agents. |
| 6. Application                   | Apply with hand tools only.  |
| 7. Clean-Up                      | Soap and water for tools and equipment.  |
| 8. Decoration                    | Ultra Fill must be completely dry prior to subsequent applications of any finishing compounds or paint.  |

 Submittal Approvals

 Job Name:

 Contractor:
 Date:

Tel: (714) 974-6837 • Tel: (866) 974-6837 • Fax: (714) 637-9033 • Fax: (866) 637-9033 341 West Meats Avenue • Orange, California 92865 • www.westpacmaterials.com